

# **MANUAL**

## **MODELS LX1, LX2, LX3**

## Table of Contents

I.	Haskris Contact Information .....	4
II.	Technical Requirements	
	Dimensions.....	5
	Clearances.....	5
	Location .....	6
III.	Installation	
	Line Sizing.....	8
	Piping.....	9
	Electrical .....	10
	Filling the Reservoir.....	11
IV.	Startup	
	50/60Hz Selection Switch .....	12
	ON/OFF Switch .....	13
	Pump Priming .....	14
	Bypass Pressure Relief Valve.....	15
	Final Checks .....	16
V.	Controller Display	
	Main Display .....	17
	Status Modes.....	17
	Adjusting Set Value (sv) .....	18
	Units of Measure.....	19
	Faults.....	20

**VI. Remote Communication Capability**

Remote Communication Options .....	22
Modbus and BACnet.....	22

**VII. Maintenance**

Condenser Coils .....	24
Suction Strainer .....	24
Particle Filter .....	25
Wye Strainer.....	25
Liquid Level and Water Quality .....	26

## **I. Haskris Contact Information**

Contact Haskris with any questions about a unit and/or the information in this manual. Haskris has a team of engineers available to answer questions, troubleshoot issues, or provide supplemental information as needed.

Phone: 001 847 956 6420

Email: [service@haskris.com](mailto:service@haskris.com) or [sales@haskris.com](mailto:sales@haskris.com)

## II. Technical Requirements

### Dimensions

- Note that the dimensions below are for the majority of standard configurations. Some units may have custom dimensions according to alternative design configurations.
- Dimensions of LX1 and LX2 are 15" W x 32" D x 30" H (38.1cm W x 81.3cm D x 76.2cm H)
- Dimensions of LX3 are 19" W x 34" D x 34" H (48.3cm W x 86.4cm D x 86.4cm H)

### Clearances

- Maintain at least 6 inches (15 cm) clearance on the sides and rear for sufficient air flow.
- Maintain at least 36 inches (91 cm) on the front for access to the main controller during normal operation.
- Maintain access to the top of the unit.
- Additional clearances on the sides and rear may be required for service.

## Location

- Locate the unit in a clean indoor environment.
- For units with air-cooled condensers, confirm ambient air temperature is compatible. Confirm the climate control system has enough spare capacity to accept heat rejection from the chiller. Refer to the table below.


Haskris Chiller Model	Standard Ambient Air Temperature*	Maximum Heat Rejection To Air
LX1	55°F to 90°F (13°C to 32°C)	7,510 BTU/hr (2.2 kW)
LX2	55°F to 90°F (13°C to 32°C)	15,020 BTU/hr (4.4 kW)
LX3	55°F to 90°F (13°C to 32°C)	29,700 BTU/hr (8.7 kW)

*\*Some units are designed with customizations to accommodate extended ambient temperature ranges, contact Haskris with any questions*

*Air-cooled Condenser: Compatible ambient air temperature ranges and heat rejection*

- For units with water-cooled condensers, confirm the building water source can provide water at the required temperature and flow rate. Refer to the chart below.
  - Install hand valves in an accessible location on the facility water inlet and outlet.
  - Install an 80 mesh wye strainer on the facility water inlet. Do not install filters.
  - Confirm the maximum inlet pressure is less than 100 psi (6.9 bar)
  - Confirm the minimum available differential pressure is 10 psi (0.7 bar)
  - Confirm the maximum differential pressure is 100 psi (6.9 bar)

Model	Multiplier
LX1	0.9
LX2	1.3
LX3	2.9



*Water-cooled Condenser: Required facility water flow rate*

## III. Installation

### Line Sizing

Contact Haskris for help: Haskris is available to review pipe runs, pressure drop, etc. and make recommendations for individual sites.

#### Approach to line sizing

- Size all interconnecting hose and piping equal to or larger than the connections on the chiller.
- Pressure drop in the external piping is a function of fluid flow rate, pipe inner diameter, pipe length, the number and type of fittings, and other factors.
- Generally, external piping should be sized to minimize pressure drop. Approximately 5 psi (0.34 bar) or less is a good goal.

#### For applications requiring approximately 8 LPM (2.1 GPM) or less

- If the total straight pipe length is less than 90 ft (27.4 m) use 1/2" nominal pipe size (ID).
- If the total straight pipe length is less than 250 ft (76.2 m) use 5/8" nominal pipe size (ID).
- If the total straight pipe length is less than 475 ft (144.8 m) use 3/4" nominal pipe size (ID).

#### For applications requiring approximately 16 LPM (4.2 GPM) or less

- If the total straight pipe length is less than 25 ft (7.6 m) use 1/2" nominal pipe size (ID).
- If the total straight pipe length is less than 75 ft (22.9 m) use 5/8" nominal pipe size (ID).
- If the total straight pipe length is less than 140 ft (42.7 m) use 3/4" nominal pipe size (ID).
- If the total straight pipe length is less than 550 ft (167.6 m) use 1" nominal pipe size (ID).

#### For applications requiring approximately 23 LPM (6.1 GPM) or less

- If the total straight pipe length is less than 40 ft (7.6 m) use 5/8" nominal pipe size (ID).
- If the total straight pipe length is less than 75 ft (22.9 m) use 3/4" nominal pipe size (ID).
- If the total straight pipe length is less than 300 ft (91.4 m) use 1" nominal pipe size (ID).



## Piping

- Comply with local codes for proper piping.
- For short runs, use opaque 150 psi minimum rated reinforced EPDM hose. Do not use clear braided hose.
- For long runs, use copper piping. Terminate the beginning and end of hard runs with vibration isolators or a short segment of hose to absorb vibration.
- Insulate piping to minimize condensation.
- Label supply and return lines over insulation with arrows indicating flow directions.
- Install isolation ball valves on the supply and return connections at the chiller.
- For water-cooled units, it is recommended to install an 80-mesh wye strainer at the building water inlet. This will provide some protection for the chiller's condenser if the facility water has particulate contaminants.

## Electrical

- Comply with proper local electrical codes.
- Contact a licensed electrician to perform the electrical installation.
- The electrician should verify that the wiring is adequate in the installation area.
- Refer to the nameplate label on the rear of the unit for detailed electrical requirements.

**Power cord:** Some units include a power cord. Hardwire the power cord to an electrical service disconnect or add a plug with the appropriate rating and type.







For units without a power cord, connect incoming power to the labeled terminal block inside the unit’s electrical enclosure.

**Service disconnect:** Use a dedicated service disconnect and time-delay fusing or circuit breaker per the electrical requirements on the unit’s nameplate label.

**Phase monitor:** Chillers configured for 3-phase electrical include a phase monitor. Refer to the fault indicators provided on the phase monitor and contact a licensed electrician to correct any faults.



*Phase monitor*

	LED STATUS	STATUS
GREEN		NORMAL (RELAY ON)
		RESTART (DELAY)
RED		REVERSAL
		LOSS/UB (UNBALANCE)
		LOW VOLT (UNDERVOLTAGE)
		HIGH VOLT (OVERVOLTAGE)

*Phase fault LED status patterns*

**Energizing the service:** Electrical power must be applied to the chiller at least 12 hours in advance of startup. This energizes the crankcase heater and drives out any accumulated liquid refrigerant in the compressor.

## **Filling the Reservoir**

- Remove the screw cap lid on the front of the unit to access the reservoir.
- Fill the reservoir with clean, potable (drinkable) distilled water.
- Stop filling when the water level is just below the threaded neck at the top of the reservoir.
- Make sure additional water is on hand when the unit is started up to top off the liquid level as the external piping is filled.
- Note: Some units are designed for compatibility with other fluids. Contact Haskris if you are unsure what fluids are compatible with your unit.

## IV. Startup

### 50/60Hz Selection Switch

Purpose: Some chillers have a selector switch for operation with either 50Hz or 60Hz incoming electrical frequency.

Operation: If the incoming electrical at the site is 50Hz frequency, toggle the switch to the 50Hz position. If the incoming electrical at the site is 60Hz frequency, toggle the switch to the 60Hz position.



*50/60Hz selection switch*

## ON/OFF Switch

Location: The chiller has a rocker ON/OFF switch located on the front of the chiller.

Operation: Toggle the switch to the ON position (I) to make the chiller run. Toggle the switch to the OFF position (O) to make the chiller stop. If a fault occurs, toggling the switch to OFF and then back ON will reset the fault.



*ON/OFF switch, OFF position*

Notes: Electrical power must be applied to the chiller at least 12 hours in advance of turning the unit on. This energizes the crankcase heater and drives out any accumulated liquid refrigerant in the compressor.

If unable to energize for the full 12 hours, energize for a minimum of 1 hour, switch the unit ON and wait until the compressor starts. Cycle the unit OFF and ON 3 to 4 times before leaving the unit switched ON.


## Pump Priming

Purpose: All fluid is removed from the pump head prior to shipment from Haskris. When starting the pump, it needs to be filled with fluid. This process is called priming the pump.

When the reservoir is full, the pump suction line is “flooded”. In most cases, this flooded suction will automatically prime the pump. When the chiller is turned ON, the pump will run. If the controller display shows the pump generating pressure, then the pump is primed.

If the controller display shows a low pressure <10 psi, then the pump did not automatically prime. Follow the procedure below.

1. Identify the priming plug on the face of the pump head



*Pump priming plug circled*

2. Use an adjustable or hex or Allen wrench to loosen the priming plug slightly. The plug should remain threaded into the port, but air and liquid should be able to escape.
3. Allow air and a small amount of fluid to escape
4. Tighten the priming plug

## Bypass Pressure Relief Valve

Purpose: Some chiller designs use a turbine pump. These designs also include a bypass pressure relief valve. The valve limits pressure by opening to bypass flow internal to the chiller.

The procedure below can be used to adjust the bypass pressure relief valve setting.

1. Remove the right side panel of the chiller.
2. Identify the bypass relief valve. An example picture is below.
3. On the bypass relief valve, use a wrench to loosen the nut at the base of the adjustment post.
4. Completely restrict the external cooling circuit, for example by closing a ball valve at the chiller's supply connection or kinking a hose. Look at the pressure reading on the controller or gauge.
  - o The pressure that results is the bypass relief valve setting
  - o This is the highest pressure the external system will experience if a restriction developed in the cooling circuit
5. On the bypass relief valve, use a flat head screwdriver to rotate the adjustment post.
  - o Rotate clockwise to increase pressure
  - o Rotate counterclockwise to decrease pressure
6. After a small adjustment, remove the restriction from step 4 to see how much flow and pressure results to the application.
7. If more adjustment is required, repeat steps 4 through 6 until the required flow/pressure is available to the application.
8. Use a wrench to tighten the nut at the base of the adjustment post and replace the chiller's side panel.



*Bypass pressure relief valve*


## Final Checks

- Verify that flow and pressure through the system piping meet the application requirements. Adjust bypass relief valve or modulate a valve in the external circuit as needed to achieve the required flow and pressure.
- As piping fills with fluid, the level in the tank will drop. Have water available to replenish the tank level as necessary. If the water level in the tank drops below the liquid level switch, the unit may shut down.
- Check to make sure all external piping is leak-tight and that the system is operating satisfactorily.
- If debris from the lines is deposited into the tank, drain the tank and refill with clean water.
- Allow a minimum of 15 minutes for temperature to stabilize following adjustments.



## V. Controller Display

### Main Display



Status	Indicates the state of the chiller
Set Value - Supply	The desired supply fluid temperature
Present Value - Supply	Measured supply fluid temperature
Pressure - Supply	Measured supply pressure
Flow Rate - Supply	Measured supply flow rate (if applicable)
Refrig. Pressure - Low	Refrigerant pressure in low side of the refrigerant circuit
Refrig. Pressure – High	Refrigerant pressure in high side of the refrigerant circuit

*Description of main display data*

### Status Modes





STARTUP	The ON/OFF switch is in the ON position Indicates the chiller is beginning operation. Appears while the chiller is initially working to control temperature.
ON	The ON/OFF switch is in the ON position Indicates the normal running of the chiller once sv is achieved
OFF	The physical ON/OFF switch is in the OFF position
Off by Alarm	An alarm or fault occurred and stopped the chiller
Remote OFF	The Remote ON/OFF feature is enabled, and the remote signal is either not present or is telling the chiller to be OFF

*Description of status modes*

## Adjusting Set Value (sv)

Notes: Set Value is the only adjustable value on this screen.

To change the setting, follow the procedure below.

1. To change the value, press the  button to move the blinking cursor to the value
2. Press the  or  buttons to adjust the value
3. Press the  button to move the blinking cursor to the top left corner







## Units of Measure


Purpose: Several combinations of units of measure are available depending on what is most useful.

The following units of measure are available:





- CAN (°C, psi, GPM)
- UK (°C, bar, IGM)
- USA (°F, psi, GPM)
- SI (°C, bar, LPM)

To change the units of measure, follow procedure below.

1. Begin on the main display
2. Press the  button on the controller
3. Press the  or  buttons to highlight Settings
4. Press the  button to go into that menu section
5. Press the  or  buttons until you see Unit of Measure Zone




*Units of measure screen*

6. Press the  button to move the blinking cursor around the screen
7. Press the  or  buttons to select different units of measure
8. Press the  button several times to return to the main display

## Faults

Identify if there is a fault: The  button will flash red when there is a fault.


Display faults and details: Press the  button to see fault descriptions.




*Example fault screen*


Description: Provides information about the specific fault.

Multiple faults: If only 1 fault is active, you will see 01 of 01. If multiple faults occur before the faults have been cleared, you will see ## of ## in the top right-hand corner. At the bottom you will see a time and date stamp HH:MM DD/MM/YY



*Fault reset screen*

Fault reset: Press the  button until you go past the last active fault, you will see this screen which explains how to reset faults.

Fault history: When the screen says NO ALARMS, there are no faults currently. Press the  button to see the fault history if needed.

Start and stop: In the bottom right-hand corner, certain faults will display “Start” or “Stop”. Start indicates when the fault occurred. Stop indicates when the fault was cleared.



*Example fault history screen*

<b>Common Faults</b>		
Wording	Explanation	Notes to Resolve
Liquid Level Alarm	Liquid level below liquid level switch	Check for a leak and add fluid so the level is near the reservoir cap
High Pressure Alarm	Refrigeration pressure sensor reading high	Air-cooled designs: Confirm the fan is spinning and check the condenser for debris or blockage that could reduce air flow Water-cooled designs: Confirm facility water flow and pressure is available
Low Pressure Alarm	Refrigeration pressure sensor reading low	Contact Haskris for diagnostics and troubleshooting
Phase Alarm	Phase monitor detected improper power	Check the phase monitor in the electrical enclosure, see the LED status light and error codes
Pump Overload Alarm	Pump overload contact opened	Reset alarm, check overload and push reset button if necessary, measure pump amp draw

*Description of common faults*

## VI. Remote Communication Capability

### Remote Communication Options

Purpose: Chillers can be configured by Haskris with several remote communication capabilities.

Examples include:

- Alarm contacts
- Remote ON/OFF interlock
- Modbus capability
- BACnet capability

Contact Haskris for help: Haskris is available to provide detailed information about a specific design's capabilities.







### Modbus and BACnet



























Purpose: Some facilities have centralized building monitoring systems (BMS). This requires a physical wire connection point between the chiller and the BMS as well as appropriate software in the chiller. Some chillers are equipped with the capability to communicate with a BMS.

Wiring: Designs that include Modbus or BACnet capability have a dedicated connector on the back of the unit for the BMS connections. These designs have one of two different connection types, 3-wire RS-485 (MSTP) or ethernet TCP/IP, depending on what was requested.

Settings Configurations: The communication settings in the controller must be aligned with the details of the BMS at the site.

To configure the communication settings, follow the procedure below.

1. Press the  button on the controller
2. Press the  or  buttons to highlight Service. Press the  button 2 times.
3. Enter the password as 6420
  - a. Press the  or  buttons to change 1 digit at a time

- b. Press the  button to move the blinking cursor
4. Press the  button to enter the password
5. Press the  or  buttons to highlight Communication
6. Press the  button
7. If the top of the screen does not say Communication, press the  or  buttons until it does
8. Press the  button to move the blinking cursor and select the appropriate communication option
  - a. BACnetIP Ethernet
  - b. ModbusIP Ethernet
  - c. BACnet RS-485
  - d. Modbus RS-485
9. Press the  button to return the blinking cursor to the top left corner
10. Press the  or  buttons to access the associated settings based on the selected option
11. Press the  button to move the blinking cursor around the screen. Press the  or  buttons to adjust settings. There may be multiple pages of settings including the IP address if applicable
  - a. To access the IP address settings, press the  and  buttons simultaneously for several seconds, the screen will change
  - b. First release the  button and second release the  button
  - c. Press the  to highlight SETTINGS, press the  button
  - d. Press the  to highlight TCP/IPv4 SETTINGS, press the  button
  - e. Press the  button to move the blinking cursor around the screen. Press the  or  buttons to adjust settings.
  - f. Press the  button to return the blinking cursor to the top left corner
12. After making all changes, power cycle the controller for the changes to take effect
13. Contact Haskris for support

## **VII. Maintenance**

Schedule: Inspection interval depends on environmental and operating conditions. At least every 6 to 12 months is recommended.

Activity: During each inspection, the cleanliness of water and electrical readings should be checked.

### **Condenser Coils**

Purpose: Some units have air-cooled condensers. These units have fans that pull air across the condenser coils to reject heat from the refrigeration circuit.

Maintenance: Dust and debris may collect on the condenser during normal operation. Accumulated debris restricts air flow and reduces heat transfer which affects chiller performance. Remove a side panel from the unit to access the inside face of the condenser. Use a brush to loosen compacted debris and use a vacuum to collect the debris.

### **Suction Strainer**

Purpose: Units have a nylon suction strainer in the tank to prevent debris from damaging the pump. The suction strainer is threaded into a fitting on the inside of the tank at the bottom.

Maintenance: Check the strainer for debris or biological growth. If debris is present the strainer can sometimes be cleaned, but if debris is significant or built up inside the strainer then it may need to be replaced. Replacement strainers are available from Haskris.

Notes: A dirty strainer can cause cavitation which can damage the pump. Failure due to cavitation is not covered under the warranty.



## **Particle Filter**

Purpose: Some units include a particle filter which captures debris leaving the chiller. The filter housing is mounted on the back of the unit.

Maintenance: Record the pump's running fluid pressure at the completion of startup when the filter is clean. Replace the filter when the pressure increases 5psi to 6 psi (0.3bar to 0.4 bar) above the startup running pressure. Replacement filters are available from Haskris.

## **Wye Strainer**

Purpose: Some units have water-cooled condensers. The installation may include a wye strainer which captures debris from the building water.

Maintenance: Clean the wye strainer during routine maintenance. If there is a pressure gauge between the facility water inlet and the wye strainer, then clean the wye strainer every time the pressure at the wye strainer inlet has increased 10 psi (0.7 bar) or more.

## Liquid Level and Water Quality

Purpose: Maintaining sufficient volume of clean water ensures proper operation of the unit and consistent cooling flow.

Maintenance: Check the water in the reservoir to be sure it is full of clean water.

pH: The acceptable range of pH is 7 to 10. Water absorbs CO<sub>2</sub> and pH tends to reduce over time. Add sodium bicarbonate to raise pH if needed.

Cleanliness and Flushing: The water should be free of particles and biological growth. If there is substantial debris and biological growth, consider flushing the system.

To flush the system, follow the procedure below.

1. Check with the equipment manufacturer to confirm that hydrogen peroxide is approved for temporary use
  - a. If hydrogen peroxide is approved, continue to step 2
  - b. If hydrogen peroxide is not approved, disconnect the application and connect a short hose directly from the chiller's supply connection to the return connections
2. Add 1 pint (0.5 L) of 3% hydrogen peroxide per every 15 gallons (57 L) of water to the tank
3. Circulate the solution for 20-30 minutes
4. Use the drain hose to drain the system
5. Refill the system with clean, potable distilled water
6. Repeat as necessary to fully flush the system

Glycol: If biological growth persists even after regularly changing the water and flushing the system, use laboratory/food grade (99% pure) propylene glycol to create a 10% mixture. Haskris recommends that additives be used only as a means of last resort.